

Whenever you are working in different sector of garments you may require having knowledge about the basic abbreviations used in these sectors, so that you can use it to the respective purpose. Here I tried to arrange some important abbreviations used by the engineers or workers for fabric, dyeing and printing.

Some Important abbreviation of FABRIC, DYEING and PRINTING

- CPI-Course per Inch
- CVC-Chief Value of Cotton
- CMC-Carboxyl Methyl Cellulose
- CMS-Carboxyl Methyl Starch
- CRI-Color Rendering Index
- CWF-Cool White Fluorescent
- CF-Compact Fluorescent
- CRP- Caustic Recovery Plant
- DMT- Di Methyl Terephthalate
- D65-Artificial Daylight
- EPI-Ends Per Inch
- ETP-Effluent Treatment Plant
- GLM- Gram per Linear Meter
- GSM-Grams per Square Meter
- ITET-Institute of Textile Engineers and Technologist
- PET-Poly Ethylene Terephthalate
- PVA- Poly Vinyl Amide
- PPI-Picks Per Inch
- PFD-Prepared for Dyeing
- PPM-Parts per Million
- PSI-Pounds per Square Inch
- PC Fabric- Polyester Cotton Fabric
- PTFE- Poly Tetra Fluoro Ethylene
- RPM- Revolution per Minute
- RED-Ready for Dyeing
- RH- Relative Humidity
- TC- Tetron Cotton
- TRO- Turkey Red Oil
- UV-Ultraviolet Light
- WTP-Water Treatment Plant
- WPI- Wales per Inch

Remember one thing that these abbreviations not only necessarily fixed by this meanings but it may varies and means differently in different department to department and also country to country.

<http://ordnur.com>

textile abbreviations, garments abbreviations, garments related abbreviations, ordnur
textile garments abbreviations